



Jeep JL Fuse Box Diagram

Use Fuse slot # F52 - see arrow below

